

Panel Cut-Out Template

NOTES:

1) USE PROPER SAFETY GOGGLES (ANZI Z81) AND USE CAUTION WHENEVER YOU ARE DRILLING OR CUTTING!

