

# C-NaviGator III

# Panel Cut-Out Template

**NOTES:**

1) USE PROPER SAFETY GOGGLES (ANZI Z81) AND USE CAUTION WHENEVER YOU ARE DRILLING OR CUTTING!

